

THE BRIDGE III P

Docking station for iPod and iPhone

Owner's Manual



Made for
iPod iPhone

iPhone not included

harman/kardon
by HARMAN

THE BRIDGE III P

Table of Contents

INTRODUCTION	3
FEATURES	3
INCLUDED ITEMS	3
COMPATIBILITY	3
INSTALLING	4
CHARGING THE IPOD OR IPHONE	5
UNDOCKING THE IPOD OR IPHONE	5
TROUBLESHOOTING	5
SPECIFICATIONS	5

THE BRIDGE IIIIP

Introduction, Features, Included Items and Compatibility

Introduction

Congratulations! With The Bridge IIIIP, you are entering the new world of entertainment made possible by combining the incredible storage capacity and playback flexibility of an iPod or iPhone with the sonic power of your harman kardon system.

With a single cable, your iPod or iPhone is connected, and all you need is your remote control to get started!

Features

- Single connection to a The Bridge IIIIP-ready harman kardon product
- Plays content from a compatible iPod or iPhone through your harman kardon system
- Outputs high-definition video up to 720p from compatible iPod and iPhone models, when available on the device
- Controls your iPod or iPhone, using the harman kardon remote
- Easy track selection with on-screen navigation



Included Items

- The Bridge IIIIP docking station
- Five clear dock adapters, marked "NANO," "5G (VIDEO 60GB)," "5G (VIDEO 30GB)," "13" and "12, 14"
- Black insert marked "UNIVERSAL" to accept appropriate dock adapter

Compatibility

At the time of the printing of this manual, The Bridge IIIIP is compatible with the harman kardon BDS 2, BDS 5, MAS 101, MAS 102 and MAS 111.

Made for iPod nano 5th generation, iPod touch 2nd generation, iPod classic, iPod nano 4th generation, iPod touch 1st generation, iPod nano 3rd generation, iPod with video.

Made for iPhone 4, iPhone 3GS, iPhone 3G and iPhone.

Please check www.harmankardon.com for the latest compatibility information.

Video and photo playback requires iPod model supporting video browsing and a video-capable harman kardon product.

Refer to the user manual of the compatible harman kardon product for information about operation and capabilities.

Installing

With only a single cable connection, The Bridge IIIIP is easy to connect to your harman kardon product.

Step One: Turn off the harman kardon The Bridge IIIIP-ready product, using its main power switch.

Step Two: Holding the cable with the wider part of the connector at the bottom, gently squeeze the tabs on each side as you insert it into the connector on the rear panel of the harman kardon product. See Figure 1.



Figure 1 –
The Bridge IIIIP connector

Step Three: Place the black insert in The Bridge IIIIP, making sure to push it all the way down. See Figure 2.

NOTE: Do not place an iPod or iPhone in The Bridge IIIIP unless both the black insert and a dock adapter are installed. Otherwise, the iPod or iPhone will not connect properly, and both it and The Bridge IIIIP may sustain damage that is not covered by the warranty.

Step Four: Locate the dock adapter that was included with your iPod or iPhone, or select one of the included clear dock adapters by referring to Table 1. If your iPod or iPhone does not appear in Table 1 and did not include an adapter, contact Apple Inc. to purchase one.

Place the adapter in The Bridge IIIIP insert, as shown in Figure 2.

Step Five: Remove the iPod or iPhone from any case, and dock it in The Bridge IIIIP, as shown in Figure 2.




Figure 2 – Docking an iPod or iPhone in The Bridge IIIIP

Table 1 – Select the Correct The Bridge IIIIP Dock Adapter

The Bridge IIIIP Insert	iPod Model
NANO	iPod nano, 1st generation
5G (VIDEO 60GB)	iPod, 5th generation (60GB, 80GB) and iPod classic (160GB)
5G (VIDEO 30GB)	iPod, 5th generation (30GB) and iPod classic (80GB)
13	iPod nano, 3rd and 4th generation
12, 14	iPod touch – install large bumper; iPhone 4, iPhone 3GS, iPhone 3G, iPhone – install small bumper

THE BRIDGE III P

Charging the iPod or iPhone, Undocking the iPod or iPhone, Troubleshooting and Specifications

Charging the iPod or iPhone

You may leave your iPod or iPhone in The Bridge III P even when you are not using it as a playback source. Whenever the iPod or iPhone is docked and your harman kardon product is turned on, The Bridge III P will charge the battery in the iPod or iPhone.

Undocking the iPod or iPhone

We recommend that you pause playback before physically removing the iPod or iPhone from The Bridge III P.

Troubleshooting

Symptom	Solution
The iPod or iPhone does not play or respond to commands from the harman kardon remote.	<ul style="list-style-type: none">• Make sure that The Bridge III P is properly connected to a compatible harman kardon product.• Make sure that The Bridge III P is selected as the input on the harman kardon product.

Specifications

Dimensions (H x W x D): 1-3/16" x 4-1/2" x 4-1/2" (30mm x 114mm x 114mm)

Weight: 0.37 lb (0.17kg)



Harman Consumer, Inc.
8500 Balboa Boulevard, Northridge, CA 91329 USA
516.255.4545 (USA only)

Made in P.R.C.

© 2010 Harman International Industries, Incorporated. All rights reserved.

Features, specifications and appearance are subject to change without notice.

harman kardon is a trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries. The Bridge IIIP logo is a trademark of HARMAN International Industries, Incorporated.

iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. iPod and iPhone not included. "Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Part No 950-0331-001

iPhone not included



harman/kardon
by HARMAN

www.harmankardon.com